

Installing Heater Wire Trim

TURN OFF POWER TO HEATER WIRE BEFORE INSTALLING 1" WIDE STAINLESS STEEL TRIM.

Instructions are as follows:

1. Remove existing trim by starting at the bottom of door frame. Using a wide flat blade screwdriver, insert flat blade behind back edge of trim and lift off front edge of trim (nearest door opening). Using the flat blade under the bottom of the trim work your way up to the top of the door frame. Repeat same thing on other side of door frame. Across the top of the door, repeat at either end and remove top trim.

Fit new pieces onto door frame by:

2. Slip over inner edge of extrusion, pulling over heater wire and wrap trim toward inside of door frame.
3. Using new screws, screw new trim in place. Caulk seams at top & bottom corners to ensure no moisture gets behind the trim strip and into the door jam.

TURN ON POWER TO HEATER WIRE AFTER INSTALLING NEW SS TRIM

Buy this trim at walkincoolerparts.com