

Adjust Door Sweep Height On FIP Urethane Door

- Take door off hinges and place on saw horses (This procedure cannot be done with the door hanging in place)
- Remove two screws holding sweep in place



- Remove sweep
- Make sure channel is deep enough for sweep adjustment



- A screwdriver can be used to deepen channel foam
- A drill and bit can be used to deepen channel ends through plastic
- Re-Attach sweep, a flat putty knife or screwdriver can be used to push sweep up into channel
- Re-install two screws holding sweep in place
- Put door back on hinges
- Sweep should drag slightly when door is closed the three fingers should all be touching the threshold