

Application Instructions

Recommended Supplies:



Clean, dry cloth



Surface cleaner



Surface primer



Tape measure



Application squeegee or roller



Cutting blade or knife



Edge fix

Storage & Environment Recommendations:


- Ensure that the material is kept in dry, warm conditions in the original protective packaging
- Surface should be in a low to normal humidity to avoid dampness
- Use material within 2 years of purchase for best use of product

STEP 1



Clean the area of application using our surface cleaner. Make sure surface area is clean and dry as it is essential for the material to adhere properly. All contaminants need to be removed (such as paint flakes, etc) – DO NOT use methylated spirits/gasoline/lighter fluid etc as these leave behind a thin, greasy residue.

STEP 2



Ensure prepared surface is above 50°F (10°C). Applying material to a surface that is under 50°F will not allow the adhesive to stick to the surface it is being applied to.

STEP 3



Porous surfaces must be sealed prior to application to prevent water attacking the adhesive. We recommend our own primer for this job. Apply a thin coat to the cleaned surface using a paint brush, then leave to dry.

STEP 4



Peel back part of the release liner then press the adhesive firmly onto the prepared surface and slowly keep peeling back the liner while applying the tape. Try to ensure that the tape is not taut.

STEP 5



Once applied, press tape down firmly using even pressure (our pressure roller is ideal for this). We recommend sealing the edges using “edge fix” as this will extend the life of the product. Only use a small amount down the edges, a thin bead.

If correctly applied, the new anti-slip surface can be walked on instantly. You will get maximum benefit from the adhesive system after 48 hours.